



WARNING It is advised to locate the transformer 2.5 mtrs away from the ceiling extractor.

Above is the top side of your showair extractor.

Your new ceiling hood has a transformer that reduces the electrical current from 220v - 12v Remote control operated as standard.

Your ceiling extractor can be wired to a extremal switch unit (not supplied) if you want to override the remote control, please ask a qualified electrician for advise or simply order the switch unit direct for Luxair (see spares section on our website).

Your ceiling extractor is already pre-wired to the transformer, however should you need to replace it in the future please see picture below showing the electrical connections.

Live Feed
to the
Transformer



12v to the
Ceiling
Extractor