



**LUXAIR™**  
EXTRACTION WITH ATTRACTION

## Designer Hood Remote Control Instructions Bluetooth



Frequency:  
2.4 GHz BT

Voltage: 3V

Power: Battery  
mod. AAA 1200mA  
alkaline

- 
- Temperature range: +5°C / +45°C
  - Change battery every 18 months
- 

### 24H Function

With the motor off, press button 5 for up to 10 seconds.  
The hood will now turn on and off by itself, for 5 mins every hour

## Programming/Pairing

### Push Button

- 1 - Increases motor speed
- 2 - Timer function 10 mins
- 3 - On/Off Motor. Default motor starts speed 2
- 4 - On/Off Lights
- 5 - Decrease motor speed

### Synchronise hood with remote control

- Press button 4 for up to 10 seconds until the hood makes a confirmation beep. (the hood only synchronises within 10 seconds of electrical connection)

### LED

A - Motor Speed: The number of these flashing indicates the speed of the motor. If the timer is active, the light will remain on

B - Light On/Off

C - 24H Function Active

D - Not Used