




Spare-Remote-NT-Celux Control Instructions Radio Frequency



Frequency:
433,92 MHz

Voltage: 3V

Power Type
CR2032

- Temperature range: +5°C / +45°C
- Change battery every 18 months

Programming/Pairing

- Disconnect the hood from the mains electricity supply.
- Simultaneously press the On/Off & light button for about 15seconds (or until the red LED is on) then release.
- Connect the hood back to the mains electric supply.
- Press the On/Off buttons within 5 seconds of connecting the hood to the mains.